

INSTALLATION INSTRUCTIONS

UN-59-02604-000

FloodPak with AZ Option

- ① Remove hex head bolt from top of FloodPak mounting box.
 - ② Replace with the Allen Head bolt contained in this pack.
 - ③ Mount the FloodPak Mounting Box with the Allen Head Bolt on top.
 - ④ Insert the safety cable head into the slot found in the mounting box.
 - ⑤ Make splice.
 - ⑥ Pivot FloodPak and mount at the Zero degree mark to ensure "cut-off"
- (Refer to full instruction sheet found with the FloodPak for more information.)

